

---

# ECE 375 LAB 8

Introduction to AVR Development Tools

**Lab Time: Tuesday 7-9**

*Aaron Rito and Robert Lockard*

## INTRODUCTION

Lab 8 uses the IR sensor and the USART feature to control the tekbot remotely. One board is programmed as a remote, the other as a receiver. This report details both version of code.

## PROGRAM OVERVIEW

The receiver program sets the bot to halt, and waits for a command from the remote. When a command is received, the bot will perform the action corresponding to the received opcode. If the bot receives a freeze tag signal, it sends the freeze all signal out to all bots in the area.

The transmitter program uses the IR to send commands to a specific bot. The push buttons are assigned to send different commands. When a button is hit the remote will first send out the bot iD, and then the instruction code.

## INITIALIZATION ROUTINE

The program initializes the at128 chip , and then runs a routine to initialize the stack pointer and direct access registers. Then it defines the locations for the interrupt routines. Then after the typical tekbot initialization, the USART control registers are initialized. The baud rate is set to 2400, using the UBRR USART baud rate register. Then the parity, stop bits, and character size are set using the USART control and status register. In the receiver code, the RX enable and the RX complete interrupt bits are set. A tag counter is set to 3. Then the bot is set to halt. In the transmitter code the TX enable bit is set instead of RX.

## MAIN ROUTINE

The receiver main routine is only 2 lines long. It updates PORTB with the current saved action and loops. The transmitter code polls PORTB for a button press, and then calls the appropriate function to send the action code.

## RECEIVER FUNCTIONS:

### RECEIVE\_COMMAND

The receive command function is called when the Rx complete interrupt bit is set. It compares the data in UDR1 register to the list of instruction codes, and calls the appropriate action function. If no match is found, it returns to the main loop.

### SAVE\_ACTION

The save action function simply saves the last received instruction in the mpr2 register. It's purpose is so the bot can return to its last command after being frozen or interrupted by the whisker bits.

### MOVE\_FORWARD, MOVE\_BACK, HALT, HIT\_LEFT, HIT\_RIGHT

These are the action functions for the bot. After calling the save action function, all they do is set the motors to perform the desired action. The Hit\_left and Hit\_right functions are identical to previous labs, to maintain whisker functionality. They are called with intermediate functions that save the action, so the whisker hits don't cause undefined behavior.

## FREEZE FUNCTION

The freeze function first disables all interrupts, and then sets the bot to freeze for 5 seconds. It decrements a tag counter (set to 3 in initialization) and then compares it to 0. If the tag counter has reached 0, the bot goes into a death loop.

## MSG\_OUT FUNCTION

The message out function is called when the bot is acting as a middle man for tag. It disables the RX pins, and enables the TX transmitter. Then it sends out a freeze code. After the code is sent and a short delay, the RX bits are re-enabled and the TX bit disabled. This avoids any race conditions or the bot receiving its own freeze code.

## DEATH\_LOOP FUNCTION

The death loop function is called when the tag counter has reached 0. It's sends the bot into an infinite loop with all interrupts disabled. This loop is terminal.

## TRANSMITTER FUNCTIONS:

### SEND\_BOT\_ID FUNCTION

This function sends the bot ID out through the UDR1 register. Then it has a short delay. This gets called every time a new action is sent out.

### FORWARDTX, BACKWARDTX, TURNLEFTTX, TURNRIGHTTX, HALTX

These functions are all identical except for the opcode they send out. They first call the send bit id function and then send the desired opcode. A delay "waitTX" is called that waits until the transmission is finished before returning to the main loop.

### WAITTX

Wait TX simply waits for the transmission to finish using SBRC, then returns to the main loop.

### FREEZETX

The freezeTX signal is set on an interrupt but acts the same way as the other action functions. It sends the bot id and then the opcode, then a waits for the transmission to finish. This freezes the bot.

### TAG\_SIG

The tag\_sig fucnton acts the same way as the other action functions. It sends the bot id and then the opcode, then a waits for the transmission to finish. This tells the bot to freeze other bots but not itself.

## STUDY QUESTIONS

There are no study questions for this lab.

## DIFFICULTIES

I ran out of coding space with the interrupt vectors. (Relative branch out of range error). I solved the issue by embedding the function calls using rcall within smaller branch call functions.

## CONCLUSION

The IR hardware on the tekbot can send and receive data. The USART feature on the 128 chip allows for sending and receiving up to 9bit data. The baud rate is set in the UBBR register, the parity, stopbits, and character size are set in the UCSR1C register. The interrupts and enable bits for USART are in register UCSR1B. When sending and receiving data with the same unit, care must be taken that the bot does not receive it's own transmissions. This is accomplished by disabling the TX when receiving and disabling the RX when sending.

## CITATIONS

USART ATmega328p with Assembly code to Control LED and Servo. (n.d.). Retrieved March 14, 2017, from <http://www.avrfreaks.net/forum/usart-atmega328p-assembly-code-control-led-and-servo>

(2015, December 3). Retrieved March 14, 2017, from <https://github.com/iankronquist?tab=repositories>

## RECEIVER SOURCE CODE

```
; lab8.asm

; RX code

; Created: 3/10/2017 12:22:06 PM

; Authors: Aaron Rito, Robert Lockard

.include "m128def.inc"           ; Include definition file

; Variable and Constant Declarations

.def    mpr = r16                ; Multi-Purpose Register
.def    waitcnt = r17            ; Wait Loop Counter
.def    ilcnt = r18              ; Inner Loop Counter
.def    olcnt = r19              ; Outer Loop Counter
.def    current_action = r23     ; Holds the current operation.
.def    death_counter = r24      ; keeps track of freeze tags
.def    mpr2 = r21               ; holds the commands to avoid writing over the
opcodes

.equ    WTime = 250              ; Time to wait in wait loop
.equ    TurnTime = 100           ; A shorter wait time
.equ    WskrR = 0                ; Right Whisker Input Bit
.equ    WskrL = 1                ; Left Whisker Input Bit
```

```

.equ    EngEnR = 4                ; Right Engine Enable Bit
.equ    EngEnL = 7                ; Left Engine Enable Bit
.equ    EngDirR = 5               ; Right Engine Direction Bit
.equ    EngDirL = 6               ; Left Engine Direction Bit

;These macros are the values to make the TekBot Move.

.equ    MovFwd = (1<<EngDirR|1<<EngDirL)    ; Move Forward Command
.equ    MovBck = $00                      ; Move Backward Command
.equ    TurnR = (1<<EngDirL)                ; Turn Right Command
.equ    TurnL = (1<<EngDirR)                ; Turn Left Command
.equ    Halt = (1<<EngEnR|1<<EngEnL)         ; Halt Command

.equ    BotAddress = 1                    ;(Enter your robot's address here (8
bits))

;These macros are the values to make the TekBot Move. The action codes have been set to match
them.

.equ    MovFwdR = (1<<EngDirR|1<<EngDirL)    ;0b01100000 Move Forward Action Code
.equ    MovBckR = $00                      ;0b00000000 Move Backward Action Code
.equ    TurnRR = (1<<EngDirL)                ;0b01000000 Turn Right Action Code
.equ    TurnLR = (1<<EngDirR)                ;0b00100000 Turn Left Action Code
.equ    HaltR = (1<<EngEnR|1<<EngEnL)         ;0b10010000 Halt Action Code
.equ    freeze_msg = 0b11111000            ;send the freeze out message code
.equ    freeze_sig= 0b01010101            ;freeze from any source
.equ    ser_buffer = $0100                 ;a buffer for the UDR1 register

.cseg

.org    $0000                            ; Beginning of IVs

        rjmp    INIT                      ; Reset interrupt

.org    INT0addr                          ; setting up int0

```

```

        rcall HitRight
        reti

.org INT1addr                ; setting up int1

        rcall HitLeft
        reti

.org $003C                   ; USART signal recieved

        rcall recieve_command
        reti

.org $0046                   ; End of Interrupt Vectors

INIT:

        cli

        ; Stack Pointer

        ldi        mpr, low(RAMEND)
        out        SPL, mpr

        ldi        mpr, high(RAMEND)
        out        SPH, mpr

        ;USART1 Set baudrate at 2400bps

        ldi mpr, $A0
        sts UBRR1L, mpr

        ldi mpr, $01
        sts UBRR1H, mpr

        ldi mpr, (0<<U2X1)
        sts UCSR1A, mpr

        ; Enable receive interrupt

        ldi mpr, (1<<RXCIE1) | (1<<RXEN1)

        sts UCSR1B, mpr

```

```

; Set frame format: 8 data bits, 2 stop bits

; 2 stop bits is USBS1, data bits are UCCSZ*

ldi mpr, (1<<UCSZ10) | (1<<UCSZ11) | (1<<USBS1) | (1<<UPM01)

sts UCSR1C, mpr


; Initialize Port B for output

ldi      mpr, $FF          ; Set Port B Data Direction Register
out      DDRB, mpr         ; for output

ldi      mpr, $00          ; Initialize Port B Data Register
out      PORTB, mpr        ; so all Port B outputs are low


; Initialize Port D for input

ldi      mpr, $00          ; Set Port D Data Direction Register
out      DDRD, mpr         ; for input

ldi      mpr, $FF          ; Initialize Port D Data Register
out      PORTD, mpr        ; so all Port D inputs are Tri-State


; Initialize TekBot Forward Movement

ldi      mpr, MovFwd       ; Load Move Forward Command
out      PORTB, mpr        ; Send command to motor


; set the Interrupt control state in EIRCA to falling

ldi mpr, (1 << ISC11) | (1 << ISC01)

sts EICRA, mpr


; Set the External Interrupt Mask for int0 and int1

in mpr, EIMSK

ori mpr, (1<<INT0) | (1<<INT1)

out EIMSK, mpr

ldi mpr, $03

MOV death_counter, mpr

ldi current_action, 0b10010000

```

```

        sei

;main loop

MAIN:

        out PORTB, current_action    ; sets PORTB to the saved action in case of freeze or
whisker hit

        rjmp MAIN                    ; loop back, interrupts do the rest

;USART recieve opcode command

recieve_command:

        ldi XL, low(ser_buffer)      ;set X pointer to point at UDR1 (not sure I need
this)

        ldi XH, high(ser_buffer)

        lds mpr2, UDR1               ;load the opcode

        ;the following compares the recieved opcode with the motor fucntions and calls the
appropriate action

        cpi mpr2, MovFwdR

        breq move_forward_call

        cpi mpr2, MovBckR

        breq move_back

        cpi mpr2, TurnRR

        breq HitRight_call

        cpi mpr2, TurnLR

        breq HitLeft_call

        cpi mpr2, Halt

        breq Halt_now

```



```

        cpi mpr2, freeze_sig
        breq freeze

        cpi mpr2, freeze_msg
        breq msg_out

        ret

;ran out of space on the interrupt vector space, need calls for calls
HitLeft_call:
        rcall    save_action
        rcall HitLeft
        ret

HitRight_call:
        rcall    save_action
        rcall HitRight
        ret

move_forward_call:
        rcall move_forward
        ret

;death loop after 3 freeze tags
death_loop:
        ldi mpr, $FF    ;setPORTB to all on death signal
        out PORTB, mpr
        rjmp death_loop

;Halt action
Halt_now:
        rcall    save_action                ; save the action so we can return to it
        ldi      mpr, HaltR
        out      PORTB, mpr

```

```

        ldi            waitcnt, Wtime

        rcall    wait

        ret

;freeze as a slave

freeze:

        cli

        ldi mpr, $00            ;disable the interrupts

        out EIMSK, mpr

        out EIFR, mpr

        ldi mpr, $0F

        out PORTB, mpr        ; show the freeze signal on PORTB

        ldi    waitcnt, WTime        ; Wait for 1 second

        rcall    wait

        dec death_counter        ; decrement the tag counter

        cpi death_counter, $00

        breq death_loop        ; die if tagged 3 times

        in mpr, EIMSK            ;re-enable interrpus

        ori mpr, (1<<INT0) | (1<<INT1)

        out EIMSK, mpr

        out EIFR, mpr

        sei

        ret

;freeze as a middle man

msg_out:

        ldi mpr, (0<<RXCIE1)|(0<<RXEN1) | (1<<TXEN1) ;disable the reciever, enable the transmitter

        sts UCSR1B, mpr

        ldi mpr, 0b01010101        ; send out the
freeze tag signal

        sts UDR1, mpr

```

```

        out PORTB, mpr

        ldi    waitcnt, TurnTime                ; Wait for 1
second for the transmit to finish

        rcall Wait

        ldi mpr, (1<<RXCIE1)|(1<<RXEN1) | (0<<TXEN1) ;disable transmitter, enable reciever,
avoids race condition

        sts UCSR1B, mpr

        ret

;move backwards

move_back:

        rcall  save_action          ; save the action command

        ldi    mpr, MovBck          ; Load Move back Command

        out    PORTB, mpr           ; Send command to motors

        ldi    waitcnt, TurnTime    ; Wait for 1 second

        rcall  Wait                 ; Call wait function

        ret

;move forward

move_forward:

        rcall  save_action          ;save the action command

        ldi    mpr, MovFwd          ; Load Move Forward Command

        out    PORTB, mpr           ; Send command to motors

        ldi    waitcnt, TurnTime    ; Wait for 1 second

        rcall  Wait                 ; Call wait function

        ret

;turn right, the action command is saved in the action call in case the whiskers are using the
fucntion

HitRight:

        cli                                ;disable interrrupts

        ldi mpr, $00

        out EIMSK, mpr

        out EIFR, mpr

```

```

; Move Backwards for a second

ldi      mpr, MovBck      ; Load Move Backward command
out      PORTB, mpr      ; Send command to port
ldi      waitcnt, TurnTime ; Wait for 1 second
rcall    Wait            ; Call wait function

; Turn left for a second

ldi      mpr, TurnRR      ; Load Turn Left Command
out      PORTB, mpr      ; Send command to port
ldi      waitcnt, TurnTime ; Wait for 1 second
rcall    Wait            ; Call wait function

in mpr, EIMSK                ;re-enable interrupts
ori mpr, (1<<INT0) | (1<<INT1)
out EIMSK, mpr
out EIFR, mpr
sei

ret                        ; Return from subroutine

```

;turn left, the action command is saved in the action call in case the whiskers are using the fuction

HitLeft:

```

cli

ldi mpr, $00

out EIMSK, mpr
out EIFR, mpr

; Move Backwards for a second

ldi      mpr, MovBck      ; Load Move Backward command
out      PORTB, mpr      ; Send command to port
ldi      waitcnt, TurnTime ; Wait for 1 second
rcall    Wait            ; Call wait function

```

```

; Turn right for a second

ldi          mpr, TurnLR      ; Load Turn Left Command
out          PORTB, mpr      ; Send command to port

ldi          waitcnt, TurnTime    ; Wait for 1 second

rcall Wait                    ; Call wait function


in mpr, EIMSK                  ;re-enable interrupts
ori mpr, (1<<INT0) | (1<<INT1)
out EIMSK, mpr
out EIFR, mpr
sei
ret


;the same wait function from the other labs

Wait:

    push    waitcnt            ; Save wait register
    push    ilcnt              ; Save ilcnt register
    push    olcnt              ; Save olcnt register

Loop:  ldi          olcnt, 224      ; load olcnt register
OLoop: ldi          ilcnt, 237      ; load ilcnt register
ILoop: dec          ilcnt          ; decrement ilcnt
       brne        ILoop          ; Continue Inner Loop
       dec          olcnt          ; decrement olcnt
       brne        OLoop          ; Continue Outer Loop
       dec          waitcnt        ; Decrement wait
       brne        Loop           ; Continue Wait loop


    pop     olcnt              ; Restore olcnt register
    pop     ilcnt              ; Restore ilcnt register
    pop     waitcnt            ; Restore wait register

```

```

ret                                ; Return from subroutine

; saves the action codes for certain actions.

save_action:

    MOV current_action, mpr2

    ret

```

## TRANSMITTER SOURCE CODE

```

;*****

;*

;*   Tek_Bot Transmitter

;*

;*   This Assembly code transmits the required operational

;*   commands to an identical Tek_Bot with an reciever assembly

;*   flash. This program has the ability through its IR

;*   transmitter to send out six differnt commands including:

;*   move foward, move backward, turn right, turn left, halt,

;*   and freeze.

;*

;*   This is the TRANSMIT file for Lab 8 of ECE 375

;*

;*****

;*

;*   Author: RJ Lockard & Aron Rito

;*   Date: 3/13/2017

;*

;*****

.include "m128def.inc"             ; Include definition file

```

```

;*****

;*      Internal Register Definitions and Constants
;*****

.def    mpr = r16                      ; Multi-Purpose Register

.def    ilcnt = r18                    ; Inner Loop Counter
.def    olcnt = r19                    ; Outer Loop Counter
.def    waitcnt = r20                  ; Wait Loop Counter

remote and TekBot                      ; Use these commands between the

                                           ; MSB = 1 thus:
                                           ; commands are shifted right by one
and ORed with 0b10000000 = $80

.equ    EngEnR = 4                     ; Right Engine Enable Bit
.equ    EngEnL = 7                     ; Left Engine Enable Bit
.equ    EngDirR = 5                     ; Right Engine Direction Bit
.equ    EngDirL = 6                     ; Left Engine Direction Bit

.equ    BotID = 00000001               ; 8 bit BotID specifies the id in which in which the
specific remote will connect to the specific reciever

.equ    Wtime = 50                     ; intialized wait time

.equ    MovFwd = (1<<(EngDirR)|1<<(EngDirL)) ; Move Forwards Command
.equ    MovBck = ($00)                  ; Move
Backwards Command

.equ    TurnR = (1<<(EngDirL))          ; Turn Right Command
.equ    TurnL = (1<<(EngDirR))          ; Turn Left Command
.equ    Halt = (1<<(EngEnR)|1<<(EngEnL)) ; Halt Command

```

```

;*****

;*      Start of Code Segment
;*****

.cseg                                ; Beginning of code segment

;-----
; Interrupt Vectors
;-----

.org    $0000                        ; Beginning of IVs
        rjmp    INIT                ; Reset interrupt

.org    $0002
        rcall    FreezeTX
        reti

.org    $0004
        rcall    HaltTX
        reti

.org    $0006
        rcall    tag_sig
        reti

.org    $0046                        ; End of Interrupt Vectors

;-----
; Program Initialization
;-----

INIT:

                                                ; Stack Pointer (VERY IMPORTANT!!!!)

        ldi      mpr, low(RAMEND)

```



```

out        SPL, mpr                ; Load SPL with low byte of RAMEND

ldi        mpr, high(RAMEND)

out        SPH, mpr                ; Load SPH with high byte of RAMEND


                                ; I/O Ports

ldi        mpr, $00                ; Initialize Port B for outputs

out        PORTB, mpr

ldi        mpr, $FF

out        DDRB, mpr


ldi        mpr, $FF                ; Initialize Port D for inputs

out        PORTD, mpr

ldi        mpr, $00

out        DDRD, mpr


                                ; USART1

                                ; Set baudrate at 2400bps

                                ; Set the baud rate and enable double
data rate

ldi mpr, $A0

sts UBRR1L, mpr

ldi mpr, $01

sts UBRR1H, mpr

ldi mpr, (0<<U2X1)

sts UCSR1A, mpr


                                ; Enable transmitter

ldi mpr, (1<<TXEN1)

sts UCSR1B, mpr

```

```

; Set frame format: 8 data bits, 2
stop bits

ldi mpr, (1<<UCSZ10) | (1<<UCSZ11) | (1<<USBS1) | (1<<UPM01)

sts UCSR1C, mpr

; External Interrupts
; Set the Interrupt to sense for
falling edge

; Set the External Interrupt Mask

ldi mpr, 0x0
out EICRB, mpr
ldi mpr, 0xa
sts EICRA, mpr
ldi mpr, 0x03
out EIMSK, mpr

clr mpr ; Clear mpr
out PORTB, mpr

sei ;Set the External Interrupt Mask

;-----
; Main Program
;-----

MAIN:

sbis PIND, 7 ; Set move forward command to PIND 7 (button 7)
rjmp forwardTX
sbis PIND, 6 ; Set move backward command to PIND 6 (button 6)
rjmp backwardTX
sbis PIND, 5 ; Set turn left command to PIND 5 (button 5)
rjmp turnLeftTX

```

```

        sbis PIND, 4                                ; Set turn right command to PIND 4 (button 4)

        rjmp turnRightTX

        sbis PIND, 2                                ; Set test RX bot transmittsion to test freeze and
death                                          ;

        rjmp tag_sig

        rjmp MAIN

;*****

;*      Functions and Subroutines

;*****

sendBotId:

        ldi mpr, BotID                            ; Send Bot ID command

        sts UDR1, mpr

        rcall waitTX                              ; rcall to the wait transmittion command to ensure no
double button press

        ret                                        ; return from subroutine

tag_sig:                                        ; test command to freeze rx, triggered by
Pin (button 3)

        ldi waitcnt, Wtime

        rcall wait                                ; rcall to the wait transmittion command to
ensure no double button press

        rcall sendBotId

        ldi mpr, 0b01010101                      ; Loading coresponding action opcode

        sts UDR1, mpr

        out PORTB, mpr                            ; Port the corresponding command to be transmitted

        rcall waitTX                              ; rcall to the wait transmittion command

        rjmp MAIN                                ; rjumps back to the main routine

forwardTX:                                        ; Move foward command, triggered by Pin
(button 7)

        ldi waitcnt, Wtime

        rcall wait                                ; rcall to the wait transmittion command to
ensure no double button press

```

```

rcall sendBotId

ldi mpr, MovFwd                ; Loading coresponding action opcode

sts UDR1, mpr

out PORTB, mpr                ; Port the corresponding command to be transmitted

rcall waitTX                  ; rcall to the wait transmittion command

rjmp MAIN                    ; rjumps back to the main routine


backwardTX:                    ; Move backward command, triggered by Pin 6
(button 6)

    ldi waitcnt, Wtime

    rcall wait                ; rcall to the wait transmittion command to
ensure no double button press

    rcall sendBotId

    ldi mpr, MovBck            ; Loading coresponding action opcode

    sts UDR1, mpr

    out PORTB, mpr            ; Port the corresponding command to be transmitted

    rcall waitTX              ; rcall to the wait transmittion command

    rjmp MAIN                ; rjumps back to the main routine


turnLeftTX:                    ; Move trunLeft command, triggered by Pin 5
(button 5)

    ldi waitcnt, Wtime

    rcall wait                ; rcall to the wait transmittion command to
ensure no double button press

    rcall sendBotId

    ldi mpr, TurnL            ; Loading coresponding action opcode

    sts UDR1, mpr

    out PORTB, mpr            ; Port the corresponding command to be transmitted

    rcall waitTX              ; rcall to the wait transmittion command

    rjmp MAIN                ; rjumps back to the main routine


turnRightTX:                   ; Move turnRight command, triggered by Pin 4
(button 4)

    ldi waitcnt, Wtime

```

```

        rcall wait                                ; rcall to the wait transmission command to
ensure no double button press

        rcall sendBotId

        ldi mpr, TurnR                            ; Loading coresponding action opcode

        sts UDR1, mpr

        out PORTB, mpr                            ; Port the corresponding command to be transmitted

        rcall waitTX                              ; rcall to the wait transmission command

        rjmp MAIN                                ; rjumps back to the main routine


HaltTX:                                           ; Halt command, triggered by interrupt (button 1)

        ldi waitcnt, Wtime

        rcall wait                                ; rcall to the wait transmission command to ensure no
double button press

        rcall sendBotId

        ldi mpr, Halt                            ; Loading coresponding action opcode

        sts UDR1, mpr

        out PORTB, mpr                            ; Port the corresponding command to be transmitted

        rcall waitTX                              ; rcall to the wait transmission command

        ret


FreezeTX:                                         ; FreezeTX command, triggered by interrupt
(button 0)

        ldi waitcnt, Wtime

        rcall wait                                ; rcall to the wait transmission command to
ensure no double button press

        rcall sendBotId

        ldi mpr, 0b11111000                      ; Loading coresponding action opcode

        sts UDR1, mpr

        out PORTB, mpr                            ; Port the corresponding command to be transmitted

        rcall waitTX                              ; rcall to the wait transmission command

        ret


waitTX:                                           ; Wait subroutine

        lds mpr, UCSR1A

```

```
sbrs mpr, TXC1
```

```
ret    `
```

Wait:

```
    push    waitcnt        ; Save wait register
```

```
    push    ilcnt          ; Save ilcnt register
```

```
    push    olcnt          ; Save olcnt register
```

```
Loop:  ldi      olcnt, 224    ; load olcnt register
```

```
OLoop: ldi      ilcnt, 237    ; load ilcnt register
```

```
ILoop: dec      ilcnt        ; decrement ilcnt
```

```
    brne     ILoop          ; Continue Inner Loop
```

```
    dec      olcnt          ; decrement olcnt
```

```
    brne     OLoop          ; Continue Outer Loop
```

```
    dec      waitcnt        ; Decrement wait
```

```
    brne     Loop           ; Continue Wait loop
```

```
    pop      olcnt          ; Restore olcnt register
```

```
    pop      ilcnt          ; Restore ilcnt register
```

```
    pop      waitcnt        ; Restore wait register
```

```
    ret                          ; Return from subroutine
```